


**ITA**

### Caratteristiche ed impieghi

Il sistema di accoppiamento automatico consente lavori di ispezione rapidi e razionali. Il piede di accoppiamento viene fissato sul fondo del pozetto assieme alla tubazione di mandata; **due tubi di guida lo collegano alla staffa di ancoraggio fissata al bordo della botola.** La elettropompa sommersibile viene calata lungo i tubi di guida fino a raggiungere la posizione esatta per l'accoppiamento; la **tenuta risulterà perfetta grazie al peso stesso della elettropompa ed alla guarnizione applicata.** Questa operazione può essere ripetuta innumerevoli volte e facilita particolarmente i lavori di controllo e di ispezione: la elettropompa viene semplicemente estratta dal pozetto con catena (*anche in caso di impianto allagato*), controllata o riparata e rimontata.


### Esploso - Exploded views



Pos.	Codice/Code	Descrizione	Description
1	PA 1X AISI 304	Piede	Coupling foot
2a	SA 1X AISI 304	Slitta	Coupling support
2b		Controdado	Lock nut
3	GA 1X AISI 304	Staffa tubi guida	Bracket guide pipe



### Dimensioni - Dimensions



Codice/Code	DN	DN <sub>3</sub>	I	K	L	M	Mf	X	Y	Kg.
RS.28.001.AX	1 1/4									
RS.28.002.AX	1 1/2									
RS.28.003.AX	2"									
RS.28.0011.AX	32 (PN 6)	2"	59	37,5	3/4"	130	210	85	94	5
RS.28.0021.AX	40 (PN 10/16)									
RS.28.0031.AX	50 (PN 10/16)									

Il costruttore si riserva il diritto di modificare le caratteristiche tecniche senza preavviso.

The manufacturer reserves the right to modify the technical features without previous notice.

**ENG**

### Features and used

The automatic coupling system allows quick and efficient inspection operations. The coupling foot is fastened to the bottom of the sump together with the delivery pipe; two guiding tubes connect to the anchoring bracket secured to the edge of the sump cover. The elettropump is lowered along the guiding tubes until it reaches the exact coupling position; the seal will be tight thanks to the weight of the elettropump and to the gasket applied. This operation can be repeated any number of times and it allow checking and inspection operations easier: the elettropump is simply extracted from the sump by means of a chain (even if the system is flooded), checked or repaired and reassembled.

### Installazione - Installation

