

Dolphin Power Supply

Basic Operation:

1. Plug the Power supply into an electrical outlet.

2. Press the **ON** button


The LEDs will turn on and the robot will start to operate.

If no program is selected, the robot will perform a single cleaning cycle.

3. You can program the power supply at any time.

See the relevant section below for more details on each program.

Smartphone Control
Bluetooth® Connection



Digital Power supply




Input: 100-125 AC Volts / 200-230 Volts
50-60 Hertz


Output: <30 VDC
IP 54

Weekly Timer (Optional)

Your robot has a Weekly Timer feature that enables you to set an automatic cleaning schedule for the week ahead.

When the power supply is switched on, you can press the Weekly Timer button to select one of the following cleaning schedule options for the week ahead:

-  **One click** The robot will automatically work every day for a full cycle, *that is, once a day for 7 days.*
-  **Two clicks** The robot will automatically work every alternate day for a full cycle, *that is, 4 times in a week.*
-  **Three clicks** The robot will automatically work every 3 days, *that is, 3 times in a week.*



After selecting one of the above options, the robot will start to operate at the next occurrence of the programmed start time.

Note: A fourth click will cancel the cleaning schedule program (without a visible indication).

If the robot is working in Weekly Timer mode, the Weekly Timer button constantly blinks between cycles. At the end of the week, the power supply automatically switches off and you need to reschedule the robot.

Regular/Fast Mode (Optional)

Your robot has a Fast Mode feature that enables you to select a fast cleaning cycle instead of a standard cleaning cycle.

When the LED under the Full Cycle icon  is lit: The robot will work in the **regular** manner.

When the LED under the Fast mode icon  is lit: The robot will work in **fast** mode. In this mode, the cycle duration is one hour and the robot cleans the pool floor only.

Note: Once Fast Mode is selected, the robot will continue to work in Fast Mode every time. To revert to the standard cleaning method, press the button. The LED under the Full Cycle icon will light up.



Delayed Operation *(Optional)*

Your robot has a Delay feature that enables you to delay the cleaning start time. This delay allows the dirt to settle at the bottom of the pool.

When the Power supply is switched on, you can press the Delayed Operation to delay the cleaning start time.

When the LED under the Delayed Operation icon is lit:

The robot will automatically start working after a two-hour delay. During that time, the ON button continuously blinks, waiting to start.

Once started, the **ON** button blinks continuously until the robot starts working.

This is a one-time operation. Delayed Operation needs to be activated each time it is required.



Bluetooth Connection *(Optional)*

Your robot has a Bluetooth® Connection indicator. When the LED indicator is on, it indicates that the smartphone paired with the robot is identified nearby. This only works if the phone's Bluetooth® is activated.



Refer to the Smartphone Control section for more information about smartphone connectivity.

Smartphone Control *(Optional)*

The Smartphone Control feature is available only with specific robot models. To activate it, download and activate the MyDolphin™ application.



When this LED indicator is on, it indicates one of the following:

- The robot is being programmed or was programmed using a smartphone.
- The robot is currently being operated using a smartphone.

Note: If you are programming the robot using a smartphone, it cannot be manually programmed using the Power supply.



Download the app



dolphinpoolrobot.com/mydolphin-app-ios

dolphinpoolrobot.com/mydolphin-app-android